

## CENTRE DOOR KNOBS

These non-turning knobs are often installed in the centre of entry doors as ornamentation, and to facilitate opening when used as pulls in place of pull handles. Secured by supplied bolts.



**3064**


Knob 2-3/4"  
Rose 3"

Pattern same as  
Door Knob 3056 - 2-3/4"



**3066**

Knob 3-1/4"  
Rose 4"



**3072**

Knob 3-1/4"  
Rose 6-3/4" x 4-3/4"